

How to record plate waste

The whole waste recording process is touchless.

YES

Scrape waste from plates directly into the Winnow bin.

You don't need to separate food items.

NO


Do not throw non-food items

Napkins

Utensils

₽lastic

How to change the bin



the bin from the scale.

The screen will notify you of an ongoing bin change.



After you've placed the bin back on the scale, make sure it is placed right under the camera and not touching the wall.



2. Place the new bin on the scale

Tap the **Confirm**button after you've
placed the bin back
on the scale.